



MAINTENANCE PROFESSIONAL

PO Box 258, Alexandria, KY 41001
 (859) 592-1890
www.mainproips.com



Monthly Test Report Instructions

NFPA 99 6.3.3.3.3 The LIM circuit shall be tested at intervals of not more than 1 month by actuating the LIM test switch. For a LIM circuit with automated self-test and self-calibration capabilities, this test shall be performed at intervals of not more than 12 months. Actuation of the test switch shall activate both visual and audible alarm indicators.

Room	Enter the name of the room the LIM is in or serves
LIM Location	Enter the location of the LIM (In-room, Hallway, Closet, etc.)
LIM Location Notes	If the location is not obvious by the room and location, add notes to assist with locating
Panel ID	Enter the panel name if applicable
Property Tag	Enter the property tag number if applicable
LIM Model	Enter the make/model of the LIM
Analogue/Digital	Enter if the LIM is Analogue or Digital
Self Test (Lights/alarm/silence)	Enter PASS/FAIL after completing the self test. Verifying that the normal, alarm and silence lights illuminate correctly. Verify the audible alarm is heard and then silences when the silence switch is pressed.
In Room Remote (Lights/alarm/silence)	If applicable, enter PASS/FAIL after completing the self test. Verifying that the normal, alarm and silence lights illuminate correctly. Verify the audible alarm is heard and then silences when the silence switch is pressed.
Nurse Remote (Lights/alarm/silence)	If applicable, enter PASS/FAIL after completing the self test. Verifying that the normal, alarm and silence lights illuminate correctly. Verify the audible alarm is heard and then silences when the silence switch is pressed.
Notes (issues/observations/etc.)	Enter any notes if the LIM does not pass to assist with troubleshooting or determining if LIM must be replaced.

Contact MainPro for troubleshooting assistance or repairs

(859) 592-1890 | service@mainproips.com

